1 Generator (GEN) warning lamp does not go out with speed increase

Check wiring between generator (D+) and warning lamp	
- Disconnect D+ wire from generator. - Switch ignition ON.	
Lamp does not light up	Lamp lights up

Generator or voltage regulator faulty.
See troubleshooting procedure No. 5

- Switch ignition OFF. - Disconnect wire (blue) at 32-pin connector, T32a, terminal 12, in instrument cluster. - Switch ignition ON.	
Lamp does not light up	Lamp lights up

Short to ground in D+ wire between generator, ignition starter switch and instrument cluster. Check wire according to wiring diagram.

Replace instrument cluster

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Volkswagen AG. Volkswagen AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Volkswagen AG.